

Testing and Process-Vx Spectra Multiphase Flowmeter

First Generation Trolley, Operations Procedure for Vx Spectra (SWTC)

First Generation Trolley, Operations Procedure for Vx Spectra (SWTC)

Testing and Process-Vx Spectra Multiphase Flowmeter

Table of Contents

1. First Generation Trolley, Operations Procedure (1)	1
2. First Generation Trolley, Operations Procedure (2)	14

1. First Generation Trolley, Operations Procedure (1)

Testing and Process-Singapore Well Testing Centre



Introduction

This SWI consists of steps on First generation trolley operations procedure for Vx Spectra (88mm)



This SWI is split into Document 1 and Document 2. This will be referred as Document 1.

Steps



Minimum 2 people required and in certain steps require 3 people. Caution, this operation has pinch points.

1 Tools needed

SI No	Description	Quantity
1	Torque Wrench (500-1500Nm)	1
2	Cleaning alcohol	As required
3	Lint Free Wipes	As required
4	Chesterton 785	As required
5	Overhead crane	1
6	Slings + Shackles	4 each
7	2" socket	1
8	Hub	As required
9	Hub stand	1
10	Studs + Nuts (2" size)	4 each
11	M12x140 socket head screw	2
12	M12x25 Hex head screw	4
13	M12 flat washer	4
14	19mm spanner	1
15	IX Seal ring	1
16	Top Flange	1
17	Mallet	1



Steps

i The first generation trolley will be referred to as "trolley"

2 Follow steps 3 & 4 for collection and inspection of parts


Step 3

3a Collect all required parts, tools and equipment for this task. Check their working condition as below

3b Trolley - Good working condition, no obvious damage. Check last inspection date is within a year.

3c Venturi - Check the Venturi material, size, PN, serial number and revision. Ensure there are protective covers at top/bottom, remote seal, thermowell, MVT area and windows area.

3d Tools - Ensure all necessary tools and shop supply are available and in good condition/calibration



i The top 4 rollers are used to position the Venturi in horizontal position. The hub stand is only used when the venturi is required in vertical position.



Step 4

Steps

4a Hub Stand - No scratches on sealing surfaces or obvious damage

4b Clamp - No obvious signs of damage

4c Stud bolts and nuts - No damage to threads



5 Follow steps 6 - 8 to mount Venturi in horizontal position



Use proper trolley movement guidelines such as line of sight, position, stepping and handling and SIPP.

Step 6

Steps

- | | |
|-----------|-------------------------------------------------------------------------------------------------------------------------|
| 6a | Make sure the hub stand is dismantled. If required to dismantle follow step 18 in document 2. |
| 6b | Check whether lock pins (Which is the lock mechanism) are installed to safely secure the vertical height of the rollers |
| 6c | Position the trolley in the crane area and lock the wheels |




2 people are required when moving the trolley.



Make sure the protective covers are used. This is to prevent damages on the Venturi critical surfaces.

Step 7

- | | |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| 7a | Move the Venturi crate into the crane area using a pallet jack |
| 7b | Check Venturi as per Step 3 |
| 7c | Install the 2 ringbolts on the top side and 2 ringbolts on the bottom side and ensure all the ringbolts are facing up as shown in the picture |
| 7d | Assemble 4 shackles and 4 slings and attach to the 4 ringbolts as shown in the picture. |




Ensure that Venturi is mounted horizontally in the direction of length of the trolley. Keep clear distance. Take care of pinch points. Use proper PPE. 2 person required.

Step 8

Steps

- | | |
|----|--------------------------------------------------------------------------------------------------------------------|
| 8a | Lift Venturi from the crate and place it on the 4 rollers on the trolley as shown. |
| 8b | Ensure that the Venturi is placed such that the window area is between the 4 rollers to balance center of gravity. |
| 8c | Rotate the venturi such that the window area is facing up. |
| 8d | Use a sling to secure the venturi in this orientation. |
| 8e | Remove the ringbolts, shackles and slings. |




To change the angular orientation, hold the Venturi at the 2 ends and rotate slowly.



Keep clear distance. Take care of pinch points. Use proper PPE. 2 person required.

Step 9 - Rotating Venturi for Windows assembly

- | | |
|----|--------------------------------------------------------------------------------------------------------------------------------------------------|
| 9a | After MW installation (as per SWI 101401979) is completed on one side, to orient the Venturi for windows assembly make sure step 5 is completed. |
| 9b | Rotate the venturi using hand until the windows area is facing up. |
| 9c | Ensure the Venturi is secured using the sling |



- 10** Follow steps 11 & 12 to dismount Venturi from horizontal position

Steps

Step 11

- | | |
|-----|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 11a | Check and ensure that there are protective covers at top/bottom, remote seal, thermowell and MVT area. |
| 11b | Position trolley in the middle of crane area and lock the wheels. |
| 11c | Place a foam pad/crate/wooden board on the floor beside the trolley. |
| 11d | Install 2 ringbolts each on the top and bottom side of the Venturi (Ringbolts should be facing up), 4 shackles and 4 slings on the Venturi as shown in the picture. |



This is required to facilitate installation of the 4 ringbolts.




The Venturi will be in a slant position due to the use of wooden bar.

Step 12

Steps

- | | |
|-----|-----------------------------------------------------------------------------------------|
| 12a | Place a wooden bar at the top hub side of the Venturi (Venturi is at a slant position). |
| 12b | Lift Venturi from the trolley and place it on the foam pad/crate/wooden board. |
| 12c | Remove the slings and ringbolts from the Venturi. |
| 12d | Place choke to prevent the Venturi from rolling sideways. |



- 13** Follow steps 14 & 15 to mount the hub stand on trolley



The operation requires atleast 2 person. Caution required for lifting operation. Proper PPE required.

Step 14

Steps

- | | |
|------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| 14a | Ensure Step 10 is completed. |
| 14b | Move the hub stand to the crane area. |
| 14c | Use a sling to support the weight of the hub stand i.e prepare sling to lift the hub stand. |
| 14d | Lift the hub stand slowly until there is enough space to position the trolley. |
| 14e | Move and position the trolley under the hub stand and lock the wheels. |
| 14f | There are orientation marks on the trolley and hub stand. Using these marks, orient the trolley and lower the hub stand and position on the trolley. |




Use proper Trolley movement guidelines such as line of sight, position, stepping & handling.

Step 15

Steps

- | | |
|-----|---------------------------------------------------------------------------------------------------------------------------------------------|
| 15a | Confirm the orientation is correct based on the marking on trolley. |
| 15b | Insert 2xM12 (PN 101349461) socket head screws - this acts as a lock mechanism to prevent rotation of the base. |
| 15c | Install 4xM12 (PN C20096570) hex head screws with washers (PN 100912109) to secure the stand to the base using 19mm spanner (Wrench tight). |
| 15d | Lower the sling and dismantle the sling. |



Minimum 2 people are required.


- 16** Follow steps 17 - 20 in document 1 and Steps 1-2 in document 2 to mount the Venturi in vertical orientation after windows assembly.

Step 17

Steps

- | | |
|-----|----------------------------------------------------------------------------------------------------------------------------|
| 17a | Prepare a parts trolley with clamps, nuts and studs. |
| 17b | Ensure Step 13 is completed. |
| 17c | Install the 4 ringbolts, 4 shackles and 4 slings on the top side of the Venturi and ensure sling is in tension. |
| 17d | Apply Chesterton 785 on 1 stud and by using another stud to evenly spread it out on the first 10 threads of all the studs. |
| 17e | Clean the sealing surface on the hub stand and seal ring with alcohol and lint free wipe. |

Lifting Venturi




Once the seal ring is placed on the flange, ensure that it is seated properly by checking if the seal ring is rocking.

Step 18


Steps

- | | |
|------------|-------------------------------------------------------------------------------------------------------------|
| 18a | Apply Molykote 111 on the seal ring and assemble it on the hub stand as shown in the picture. |
| 18b | Keep clear distance and lift the top side of the Venturi slowly until the Venturi is vertical. |
| 18c | Lift the Venturi above the ground and hold suspended at working height to facilitate cleaning in next step. |
| 18d | Ensure the sling is in tension and remove the bottom cover of the Venturi. |

**Step 19**


Steps

- | | |
|------------|------------------------------------------------------------------------------------------------------------------|
| 19a | Clean the sealing surface on the Venturi with alcohol and lint free wipe. |
| 19b | Install the locating pin in one of the threaded holes at the Venturi bottom surface. |
| 19c | Ensure the locating pin is fully tightened using 5.5mm allen key so that it helps in positioning on the trolley. |
| 19d | Using crane, position the Venturi above the hub stand. |

**Step 20**


Steps

20a With one person operating the crane and one person positioning the Venturi, lower the Venturi close enough and ensure the locating pin is seated properly and seal ring is in correct position.



Seat locating pin in one of the holes

20b Once good, lower the Venturi and place it on the hub stand. Do not dismantle the slings at this point, maintain the Venturi support.



Positioning of Venturi on hubstand

Result: End of document 1. Continue the assembly as per document 2 below.

END OF STANDARD WORK INSTRUCTION

2. First Generation Trolley, Operations Procedure (2)

Testing and Process-Singapore Well Testing Centre



Introduction

This is continuation of 102875432 AA-Document 1. This will be referred as Document 2.

Steps



3 people required for this step. Caution, this operation has pinch points.

Step 1 - Continue after Step 20 from 102875432_AA - Document 1 above

1a 2 person have to bring the clamps and place it around the Venturi-hub stand interface and third person to install the studs and nuts.

1b Once all the nuts and studs are inserted into the clamps, it is safe for the 2 person to release their hands.



Steps



Ensure parts trolley is stationed nearby.

Step 2

- | | |
|----|-------------------------------------------------------------------------------------------------------------------|
| 2a | Torque the nuts to 692 Nm using a torque wrench with 2" socket. |
| 2b | Perform the torqueing in two stages at 50% torque and 100% torque. |
| 2c | Remove the slings and ringbolts from the Venturi and store accordingly. Move all tooling to their home positions. |



Bolting shall be uniformly tightened to 692Nm, keeping spacing between the clamp halves the approximate equal.



Ensure that the crane, slings and shackles are certified. Checklist to be updated daily prior to any lifting operation. 3 people are required for this activity.

3

Follow steps 4 - 7 to mount blind hub for pressure test



Use a raised platform for the operation.

Step 4

Steps

- | | |
|-----------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 4a | Prepare the blind hub, clamp, seal ring, studs and nuts in a parts trolley and position in the crane area. |
| 4b | Apply Chesterton 785 on 1 stud and by using another stud to evenly spread it out on the first 10 threads of all the studs. |
| 4c | Remove the top cover on the Venturi. |
| 4d | Clean the hub sealing surface on the Venturi with alcohol and lint free wipe. |
| 4e | Apply Molykote 111 on the seal ring and place it on the Venturi. |
| 4f | Install 2 ringbolts and slings on the top side of the hub. |
| 4g | Lift the blind hub and clean the sealing surface with alcohol and lint free paper and lift further the height of the Venturi and position over the hub area of the venturi. |



Visually inspect the seal ring prior to placing the blind hub.



Once the seal ring is placed on the flange, ensure that it is seated properly by checking if the seal ring is rocking.

Step 5

Steps

- | | |
|-----------|-------------------------------------------------------------------------------------------------------------------------------------------------------|
| 5a | With one person operating the crane and one person positioning the blind hub, lower the hub close enough and ensure seal ring is in correct position. |
| 5b | Once good, lower the blind hub and place it on the Venturi. Do not dismantle the slings at this point, maintain the support. |

**Step 6**

Steps

6a 2 person have to bring the clamps and place it around the Venturi-blind hub interface and third person to install the studs and nuts.



6b Once all the nuts and studs are inserted into the clamp, it is safe for the 2 person to release their hands.



Step 7

Steps

- | | |
|----|---------------------------------------------------------------------------------------------------------------------|
| 7a | Torque the nuts to 692 Nm using a torque wrench with 2" socket. |
| 7b | Perform the torquing in two stages at 50% torque and 100% torque. |
| 7c | Remove the slings and ringbolts from the blind hub and store accordingly. Move all tooling to their home positions. |



Bolting shall be uniformly tightened to 692Nm, keeping spacing between the clamp halves the approximate equal.



Ensure that the crane, slings and shackles are certified. Checklist to be updated daily prior to any lifting operation. 3 people are required for this activity.

8

Follow steps 9 - 11 to dismount blind hub after pressure test



Use a raised platform for the operation.

Step 9

Steps

- | | |
|-----------|-------------------------------------------------------------------------------------------------------------|
| 9a | Move the trolley and position in the crane area with its wheels locked. |
| 9b | Install 2 ringbolts and slings on the top side of the hub and ensure sling is in tension. |
| 9c | Using a raised platform, 2 person to hold the clamp in place and third person to remove the studs and nuts. |



Step 10

Steps

- | | |
|------------|------------------------------------------------------------------------------------------------------------------------|
| 10a | Using torque wrench, loosen the 4 studs such that it is loose enough to dismatle screws using hand force as per below. |
| 10b | If required, use a mallet to loosen the clamp. |
| 10c | The third person to place the studs and nuts in the parts trolley once removed from clamp. |
| 10d | The two person holding the clamps shall slowly lower the clamps and place it on the parts trolley nearby. |



Step 11

Steps

- | | |
|-----|----------------------------------------------------------------------------------------------------------------------------------------------------|
| 11a | With one person operating the crane and one person positioning the blind hub, lift the blind hub slowly and move it towards the parts trolley. |
| 11b | Clean the sealing surface on the blind hub with alcohol and lint free wipe. |
| 11c | Place the blind hub on the parts trolley with a cloth/lint free paper between, remove the slings and ringbolts from the hub and store accordingly. |
| 11d | Remove the seal rings from the Venturi and clean using alcohol and lint free paper. |
| 11e | Clean the sealing surface on the Venturi with alcohol and lint free paper and assemble the top cover. |
| 11f | Move all tooling to their home positions. |



Make sure you are not in the zone of fall of the meter. 3 people required for task.

12

Follow steps 13 - 17 to dismount the completed meter from the trolley



Use proper trolley movement guidelines (Line of sight, position, stepping).



Make sure the assembly is lifted with tension rather than slack to ensure it does not fall after loosening flange bolts.

Steps

Step 13

- | | |
|------------|----------------------------------------------------------------------------------------------------------------------------------------|
| 13a | Push final assembly to crane area for unloading from the trolley. |
| 13b | Secure to the Venturi 4 ringbolts with 4 slings, 4 shackles and lift the slings until there is tension. |
| 13c | Position a parts trolley nearby and lock the wheels. |
| 13d | 2 person to hold the clamps at the Venturi-hub stand interface and third person to loosen the nuts using torque wrench with 2" socket. |



Ensure the stoppers on both side of the trolley are engaged and trolley does not move.



Take note that clamps are heavy and require caution during handling.

Step 14


Steps

- | | |
|------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 14a | Once the nuts are loose, use handforce to loosen further but do not remove the studs. |
| 14b | If required, use a mallet to loosen the clamp. |
| 14c | 2 person to hold the clamps and 3rd person to remove the studs and nuts and place on parts trolley. |
| 14d | 2 person to move the clamps to parts trolley. |
| 14e | With one person operating the crane and one person positioning the Venturi, lift the Venturi and suspend at working height to clean the bottom side of the Venturi. |



Step 15

- | | |
|------------|-----------------------------------------------------------------------------------------------------------------------|
| 15a | Uninstall the locating pin using a 5.5mm allen key, put in a plastic cover and tie it to the cover using a cable tie. |
| 15b | Move the trolley away from the crane area. |
| 15c | Clean the sealing surface with alcohol and lint free wipe. |



2 people are required for movement of trolley.

Steps




Maintain meter suspended until it is confirmed that meter is stable on the pallet.

Step 16

Steps

- | | |
|------------|---------------------------------------------------------------------------------------------|
| 16a | Place a pallet under the suspended venturi with a wooden plate and rubber mat as in picture |
| 16b | Lower the Venturi and place it on the pallet. |
| 16c | Do not dismantle the slings at this point, maintain the Venturi support. |
| 16d | Once placed on pallet, check if the meter is stable. |
| 16e | If not, adjust position on pallet as required. |



Steps



The meter should be positioned on the pallet in such a way to balance the center of gravity as shown in picture.

Step 17

17a Once stable, secure the meter to the pallet with additional support such as strings/slides as shown in picture

17b Remove the slings and ringbolts from the Venturi.



Ensure that the crane, slings and shackles are certified. Checklist to be updated daily prior to any lifting operation. 2 people are required for this activity.

18 Follow steps 19 & 20 to dismount hub stand from trolley.



Use proper Trolley movement guidelines such as line of sight, position, stepping & handling and SIPP and PPE.



Take care of pick points

Step 19

Steps


- | | |
|------------|----------------------------------------------------------------------------------------------------------------------------|
| 19a | Move the trolley installed with hub stand to the crane area. Position the trolley and lock in position using the stoppers. |
| 19b | Check if there is Seal ring on the stand. If available remove and clean using alcohol. |
| 19c | Prepare the sling to support the weight of the stand i.e sling should be in tension. |
| 19d | Un-install 4xM12 (PN C20096570) hex head screws with using 19mm spanner. |
| 19e | Store the screws and washers (PN 100912109) in the hub parts trolley. |
| 19f | Un-install the 2xM12 (PN 101349461) socket head screws that provides the lock mechanism and store in hub parts trolley. |



Step 20

Steps

20a	Lift the stand slowly until there is enough space between trolley and the hub stand.
20b	Lower and positioned the hub stand on the floor in vertical direction.
20c	Lower the sling further and dismantle sling.
20d	Place a protection cover such as rubber mat on the hub stand sealing surface.
20e	Move the hub stand to its storage location.
20f	Move the crane and slings to home position.



Result: End of first generation trolley operation procedure.

END OF STANDARD WORK INSTRUCTION

END OF STANDARD WORK SET



This symbol means that the equipment cannot be discarded in a rubbish-bin. At its end of life, the equipment and/or its components must be treated, following Schlumberger Environmental procedures, in compliance with Schlumberger QHSE Policy and applicable laws and regulations on waste management.

© Copyright 2017, Schlumberger, Inc. All rights reserved.

This publication contains the confidential and proprietary information of Schlumberger Technology Corporation and its affiliates (collectively "Schlumberger"). No part of this publication may be reproduced, transferred, distributed, translated, disclosed or used in any form or by any means, electronic or mechanical, in whole or in part, without the express written permission of Schlumberger. The contents of this publication are subject to change without notice. SPS, "Do It Right" is a mark of Schlumberger.